




DESBROZADORA DUCATI DBC5201TS REF. DBC5201TS

PAG	POS	REFERENCIA	DESCRIPCION
P1	1	DBC5201T/P1/1	TORNILLO MOTOR DBC5201T-S
P1	2	DBC5201T/P1/2	SOPORTE DEPOSITO MOTOR DBC5201T-S
P1	14	DBC5201T/P1/14	POLEA ARRANCADORA MOTOR DBC5201T-S
P1	15	DBC5201T/P1/15	RETEN MOTOR DBC5201T-S
P1	16	DBC5201T/P1/16	CARTER IZQ MOTOR DBC5201T-S
P1	17	DBC5201T/P1/17	JUNTA CARTER MOTOR DBC5201T-S
P1	18	DBC5201T/P1/18	RODAMIENTO MOTOR DBC5201T-S
P1	19	DBC5201T/P1/19	CIGÜEÑAL MOTOR DBC5201T-S
P1	20	DBC5201T/P1/20	JAULA AGUJAS MOTOR DBC5201T-S
P1	21	DBC5201T/P1/21	PISTON MOTOR DBC5201T-S
P1	22	DBC5201T/P1/22	BULON MOTOR DBC5201T-S
P1	23	DBC5201T/P1/23	CLIP BULON MOTOR DBC5201T-S
P1	24	DBC5201T/P1/24	SEGMENTO MOTOR DBC5201T-S
P1	25	DBC5201T/P1/25	CHAVETA MOTOR DBC5201T-S
P1	26	DBC5201T/P1/26	RODAMIENTO MOTOR DBC5201T-S
P1	27	DBC5201T/P1/27	CENTRADOR MOTOR DBC5201T-S
P1	28	DBC5201T/P1/28	CARTER DRCH MOTOR DBC5201T-S
P1	29	DBC5201T/P1/29	CENTRADOR MOTOR DBC5201T-S
P1	30	DBC5201T/P1/30	RETEN MOTOR DBC5201T-S
P1	31	DBC5201T/P1/31	TORNILLO MOTOR DBC5201T-S
P1	32	DBC5201T/P1/32	VOLANTE DE ARRANQUE MOTOR DBC5201T-S
P1	33	DBC5201T/P1/33	TUERCA MOTOR DBC5201T-S
P1	34	DBC5201T/P1/34	ARANDELA MOTOR DBC5201T-S
P1	35/36	DBC5201T/P1/35/36	EMBRAGUE COMPLETO MOTOR DBC5201T-S
P1	37	DBC5201T/P1/37	ARANDELA AJUSTE MOTOR DBC5201T-S
P1	38	DBC5201T/P1/38	TORNILLO EMBRAGUE MOTOR DBC5201T-S
P1	39	DBC5201T/P1/39	CABLE MASA MOTOR DBC5201T-S
P1	40	DBC5201TS/P1/40	BOBINA DE ARRANQUE MOTOR DBC5201T-S
P1	41	DBC5201T/P1/41	TORNILLO MOTOR DBC5201T-S
P1	55	DBC5201T/P1/55	ELEMENTO FILTRO AIRE MOTOR DBC5201T-S
P1	63	DBC5201T/P1/63	CARBURADOR MOTOR DBC5201T
P1	64	DBC5201T/P1/64	JUNTA CARBURADOR MOTOR DBC5201T-S
P1	65	DBC5201T/P1/65	TORNILLO MOTOR DBC5201T-S
P1	66	DBC5201T/P1/66	SEPARADOR TERMICO MOTOR DBC5201T-S
P1	67	DBC5201T/P1/67	JUNTA ADMISION MOTOR DBC5201T-S
P1	68	CTR7L	BUJIA MOTOR DBC5201T-S
P1	69	DBC5201T/P1/69	TORNILLO MOTOR DBC5201T-S
P1	69	DBC5201T/P1/70	CILINDRO MOTOR DBC5201T-S
P1	71	DBC5201T/P1/71	JUNTA CILINDRO MOTOR DBC5201T-S
P1	72	DBC5201T/P1/72	JUNTA SILENCIOSO MOTOR DBC5201T




PAG	POS	REFERENCIA	DESCRIPCION
P1	73	DBC5201TS/P1/73	SILENCIOSO MOTOR DBC5201T
P1	74	DBC5201T/P1/74	TORNILLO MOTOR DBC5201T-S
P1	75	DBC5201T/P1/75	TORNILLO MOTOR DBC5201T-S
P1	76	DBC5201T/P1/76	TAPA BUJIA MOTOR DBC5201T-S
P1	77	DBC5201T/P1/77	TORNILLO MOTOR DBC5201T-S
P1	78	DBC5201T/P1/78	TORNILLO MOTOR DBC5201T-S
P1	79	DBC5201T/P1/79	TAPA MOTOR MOTOR DBC5201T-S
P1	95	DBC5201T/P1/95	SOPORTE PROTECTOR DEPOSITO MOTOR DBC5201T-S
P1	96	DBC5201T/P1/96	TORNILLO MOTOR DBC5201T-S
P1	ZC2	DBC5201T/P1/ZC2	ARRANCADOR COMPLETO MOTOR DBC5201T-S
P1	ZC3	DBC5201T/P1/ZC3	TAPON DEPOSITO COMPLETO MOTOR DBC5201T-S
P1	ZC4	DBC5201T/P1/ZC4	DEPOSITO COMPLETO MOTOR DBC5201T-S
P1	ZC5	DBC5201T/P1/ZC5	CAMPANA EMBRAGUE COMPLETA MOTOR DBC5201T-S
P1	ZC6	DBC5201T/P1/ZC6	ANCLAJE FILTRO AIRE COMPLETO MOTOR DBC5201T-S
P1	ZC7	DBC5201TS/P1/ZC7	KIT CILINDRO Y PISTON MOTOR DBC5201T

P1



DESBROZADORA DUCATI DBC5201TS REF. DBC5201TS



P2

PAG	POS	REFERENCIA	DESCRIPCION
P2	1	DBC5201TSM	MOTOR GASOLINA COMPLETO DBC5201T
P2	2	DBC5201T/P2/2	ANCLAJE MANILLAR COMPLETO DBC5201T-S
P2	6	DBC5201T/P2/6	EJE TRANSMISION COMPLETO DBC5201T-S
P2	7	DBC5201T/P2/7	PROTECTOR DISCO COMPLETO DBC5201T-S
P2	9	DBC5201T/P2/9	CODO TRANSMISION COMPLETO DBC5201T-S
P2	14	DBC5201T/P2/14	ANCLAJE ARNES COMPLETO DBC5201T-S
P2	15	DBC5201T/P2/15	MANILLAR CON ACELERADOR DBC5201T-S
P2	22	DBC5201T/P2/22	CABEZAL NYLON DBC5201T-S
P2	23	DBC5201T/P2/23	DISCO 3 PUNTAS DBC5201T-S